

Troubleshooting error message on the Kudos GPS maps

Improper operation of the maps can lead to problems, such as no response of the GPS icon, application error when running the GPS or no response on touchscreen whilst in the GPS mode.

Please follow these instructions to start the GPS:

- 1: Insert the GPS card before the unit starts.
- 2: Set the GPS file path in GPS settings.
- 3: Click into the GPS mode.

Some main causes for the problem:

- 1: The GPS card is inserted after the unit is powered on.
- 2: Removing the GPS card when the GPS is still running (this may damage the GPS data on the card)

Solutions to the problem:


- 1: Power off the unit, insert the GPS card again before then restarting the unit.
- 2: Restart the unit when the error occurs.
- 3: Repair the GPS data on the card via your PC (refer to the instructions below).

Likely you will be presented with this error message:




How to fix it:

- 1: Insert the GPS card into a card reader and open on a windows PC
- 2: Select "Scan and Fix" when the dialog window appears on your PC:



3: Now select "Repair this drive".



3: The repair will start:



4: Close the dialog field after the repair is completed.

Error Checking (USB Drive (D:))

Your drive was successfully scanned

Windows successfully scanned the drive. No errors were found.

Close

[Show Details](#)

If this does not help, please contact XTRONS customer support for further assistance!